



# CAN Bus Gateway Side Board User's Manual

1. UART BTR = 38400  
 Data bit = 8  
 Stop bit = 1  
 Odd / Even parity = None  
 CANBUS BTR = 500k
2. UART DATA T/R : send / receive = 40 byte once



## Function

1. Press 1 time @ 0.5s, send 1 time(40 Byte), Order = 5, ID# = 10(Default)
2. Press 2 times @ 0.5s, ID Code - 1, ID# cycles from 16 to 1
3. Long press, time > 0.5s, ID Code +1, ID# cycles from 1 to 16



Has yellow label : With a internal terminal resistor.(120 ohm)  
 Placed at the end of CANBUS.

No yellow label : No terminal resistor.